

Automatic Audio Recording

Add a folder to save your audio files in called **recordings**

Open /etc/asterisk/rpt.conf

look for **archivedir** if you don't see it just add it under ; **MISC. SETTINGS**

Add /recordings

e.g. archivedir = /recordings

Save & reboot.

Now whenever someone keys up it will record it.

Notes:

1. Use a Large SD card.
2. Clear the folder daily or it will crash your system.
3. Turn it off when you don't need it.