

Weather with Time Announcement

This can be done two ways or both.

1. Top of the hour time with weather
2. DTMF *81 time with weather

Option 1:

SSH into your pi and start a bash shell terminal

Enter: `crontab -e`

Arrow down to this string below

```
00 0-23 * * * (source /usr/local/etc/allstar.env ; /usr/bin/nice -19 /usr/bin/perl /usr/local/sbin/saytime.pl $NODE1 > /dev/null)
```

Add your zip code.

```
00 0-23 * * * (source /usr/local/etc/allstar.env ; /usr/bin/nice -19 /usr/bin/perl /usr/local/sbin/saytime.pl ZIP $NODE1 > /dev/null)
```

Ctrl + O to save

Ctrl + X to exit

Option 2:

SSH into your pi and navigate to the `rpt.conf` file.

`/etc/asterisk/rpt.conf`

Find in your nodes stanza.

```
81=cmd,/usr/local/sbin/saytime.pl <NODE #>
```

Add your zip code.

```
81=cmd,/usr/local/sbin/saytime.pl ZIP CODE <NODE #>
```

Save & restart the node.